

Type N4DCL Combination Lock Management – Code Change



1/ Enter the correct code for the lock [in this case 1234]



2/ Press and hold in the button on the side of the lock and rotate the dials to the code you want to change the lock to [in this case 5678]



3/ release the button, the lock is now set to the new code [in this case 5678]



4/ scramble the dials to lock the lock

If you have any problems please e-mail enquiries@locker.rentals